

DASH 8 'GSB' CROSS REFERENCE GUIDE

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
14-6881-0010	14-6881-0010	14-6881-0000	TOOL-BRAKE DISC ALIGNMENT	
GSB0700007	R-1117	02-8014-4000	ADAPTER-JACK, FRONT FUSELAGE	
GSB0700008	02-7802-0111	02-8112-0111	Jack- Wing	R-1988
GSB0700009	02-0522-0140	02-8003-0140	JACK FORWARD FUSELAGE	R-1117
GSB0700010	03-5819-0000	03-8016-0010	Stand- Tail Support	
GSB0700011	03-5821-0000	03-8127-0000	Stand- Tail Support	
GSB0700012	03-5820-0000	03-8109-5000	Jury Strut Tail Support	
GSB0700013	K-1043-16	02-8020-0000	Air Assist Kit-Wing Jack	
GSB0700014	K-1043-03	02-8021-0000	Air Assist Kit-Nose Jack	
GSB0700015	K-1106	02-8022-0010	Air Manifold Kit	
GSB0700016	02-7813-0100	02-8124-0100	Jack - Axle	
GSB0700017	R-1988		ADAPTER-JACK, WING	
GSB0700019	02-7839-0111	02-7839-0100	Jack-Wing	R-1988
GSB0700020	02A7848-0110		JACK-FRONT FUSELAGE	R-1117
GSB0700021	K-1043-28-02		Included with 02A7848- 0110 Nose Tripod Jack	
GSB0700024	03-5829-0000		Stand- Tail Support (400)	
GSB0800002	99-8088-9000		Measuring Adapters-Nose and Main Wheel	
GSB0900001	01-0590-0000	01-8000-0000	Towhead Assembly (DASH 8-100/300)	(Used with 01-1277-0010 or 01 1201-0010)
GSB0900002	01-1277-0010	01-8001-0000	Towbar	(Alternate 01-1201-0010)
GSB0900003	01-1216-0000	01-8108-0000	Portable Towbar	
GSB0900004	01-0400-0000		TOWHEAD ASSY (USE WITH GSB0900005 & GSB0900003)	(Used with 01-1277-0010 or 01 1201-0010)
GSB0900005	01-1201-0010		TOWBAR (USE WITH GSB0900004)	
GSB1000003	99-8133-6000	99-8032-6000	Covers- Engine Air Intake	
GSB1000005	99-8031-6000		Cover - Engine Exhaust	
GSB1000006	99-8035-6000		Cover - Pitot Head	
GSB1000008	99-8036-6000		Propeller Restraint	
GSB1000009	99-8078-6000		Propeller Restraint - Passenger Safety	
GSB1000010	99-8114-6000		Propeller Restraint - Passenger Safety	
GSB1000011	99-8111-6000		Boot Engine Air Intake	
GSB1000013	99-8037-6000		Cover - Static Port	
GSB1000014	99-8033-6000		Cover - MLG Wheels (Standard Tires)	

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
GSB1000015	99-8033-6001		Cover - MLG Wheel (High Flotation Tires)	
GSB1000016	99-8034-6001		Cover - NLG Wheel (High Flotation Tires)	
GSB1000017	99-8034-6000		Cover - NLG Wheels (Standard Tires)	
GSB1000019	Change in process	99-8038-4000	Pin - MLG Door Ground Lock	
GSB1000020	Change in process	99-8039-4010	Pin - NLG Door Ground Lock	
GSB1000021	99-8006-6000-A2	99-8006-6000-A1, 99-8006-6001	Flyaway Kit-(GSE) (100/200)	
GSB1000023	99-8113-6001-A2	99-8113-6001-A1, 99-8113-6000	Flyaway Kit - (GSE) -300	
GSB1000024	99-8115-9000		Alpha Vane Cover	
GSB1200003	04-6029-5111	04-8099-1100	Engine Work Stand	
GSB1200012	04-6000-0910	04-6000-0900	HOIST-FORWARD BATTERY	
GSB1210001	99-9018-6011	99-8095-6011	Landing Gear Strut Service Kit	
GSB1210003	KHC-1012	06-8011-6400	Reservoir Servicing - Quick Disconnect Coupling	
GSB1210004	06-4035-3600 + KHC-1012	06-8012-3600	Hydraulic Fluid Dispenser	
GSB1210005	06-5042-3600	06-5021-3600, 06-8120-3600	Hydraulic Reservoir - Servicing Unit (Single Can)	
GSB1210006	06-5043-3600	06-5021-3600, 06-8119-3600	Hydraulic Reservoir - Servicing Unit	
GSB1210007	06-4005-3611 + KHC-1012	06-8084-3610	Portable Hydraulic Service Unit	
GSB1210009	06-4005-0511	06-8084-0510	Portable Hydraulic Service Unit (Landing Gear)	
GSB1210011	06-4005-0800 (FOR ENGINE OIL)	06-4005-0511 (FOR ENGINE OIL)	SERVICING UNIT-2 QT. PORTABLE ENGINE OIL SERVICING (0-3000 PSI)	
GSB1210012	K-2717	99-8081-6000	Oxygen Charging Adapter Kit	
GSB1210014	07-3008-6900	07-3002-6010, 07-8040-6010	Fuel Sample Unit	
GSB1210016	14-6831-6010		STRUT SERVICE GAUGE	
GSB1210017	06-5022-6800	ENGINE OIL SERVICING UNIT - PORTABLE, 2 GAL. (200 PSI MAX.)		
GSB1216001	18-4201-1010		INTENSIFIER - NITROGEN GAS, SHOP AIR POWERED)	

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
GSB1216005	14-6802-6000		TOOL - TIRE DEFLATION	
GSB1216008	14-6877-6012	14-6877-6010	GUAGE-TIRE SERVICING	
GSB1216010	14-6804-6000		KIT - CHARGING AND GAUGING HIGH PRESSURE NIT. (0-3000PSI)	
GSB1216012	14-6808-6000		KIT - CHARGING AND GAUGING LOW PRESSURE NIT. (0-500PSI)	
GSB1216019	12-3104-0000		CART - NITROGEN, 4 BOTTLES	
GSB1220002	10-4036-0010 + K-2410 + K-2029	10-8049-0010	Lavatory Service Unit	
GSB1220003	10-6402-0010 + K-2410 + K-2029		CART TOILET/LAVATORY SERVICING 68 GAL./31 GAL. WATER REPLENISH	
GSB2130002	99-8083-6000		Normal Outflow Valve Test Hose	
GSB2400007	92-8052-6000 92-8052-6001 92-8052-6002		Electrical and Avionics Tool Kit	OBSOLETE, REPL. WITH GSB2400007
GSB2400010	11-8100-6000		Electrical Contact Pin and Socket Set	
GSB2440002	11-6647-1000	11-8073-1000	D.C. Rectifier	OBSOLETE, REPL. WITH GSB2440006
GSB2440006	11-6647-1000	11-6621-1000	CART-RECTIFIER, FOR 28VDC POWER (3PHASE 50/60HZ)	
GSB2611004	99-8025-6000 99-8025-6000-A1		Fire Detection Test Unit-120 VAC Fire Detection Test Unit-220 VAC	
GSB2700006	99-8030-6010		Rigging Pin Set	
GSB2730001	99-8058-4000		Lift Transducer Calibration Kit	
GSB2750001	99-8107-6000		Right Angle Drive Adapter	
GSB2752002	99-8089-6000		Torque Sensor Tool	
GSB2810001	07-8017-6000		Fuel Drain Valve Tool	
GSB2810006	07-8018-4000		Fuel Tank Pressure Relief Test Unit	
GSB2840002	07-8091-6000		Digital Fuel Quantity Test Set	
GSB2840006	07-8019-4000		Auxiliary Fuel Pump Clamp ring Wrench	
GSB2840007	07-8066-4000		Auxiliary Fuel Pump Door Valve Puller	

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
GSB2900002	KHC-3754	KHC-2713, 05-8010-6400	Hydraulic Coupling Kit	
GSB2900003	K-3901		ADAPTOR - HEAT EXCHANGER FLUSHING	
GSB2900005	5H310ZZ5	05-7023-3400OPT84 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (200V 50HZ)	
GSB2900006	5H310ZZ9	05-7023-3400OPT88 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (440V 50HZ)	
GSB2900007	5H310ZZ6	05-7023-3400OPT85 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (220V 50HZ)	
GSB2900008	5H310ZZ7	05-7023-3400OPT86 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (380V 50HZ)	
GSB2900009	5H310ZZ8	05-7023-3400OPT87 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (415V 50HZ)	
GSB2900010	5H310ZZ3	05-7023-3400OPT82 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (460V 60HZ)	
GSB2900011	5H310ZZ4	05-7023-3400OPT83 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (575V 60HZ)	
GSB2900012	5H310ZZ0	05-7023-3400OPT80 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (208V 60HZ)	
GSB2900013	5H310ZZ1	05-7023-3400OPT81 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (230V 60HZ)	
GSB2900014	5H310ZZ2	05-7023-3400OPT89 +OPT06 + OPT07 + OPT08 + OPT21	UNIT-HYDRAULIC POWER, 9-11 GPM (380V 60HZ)	
GSB2900015	56310GG0BC	05-7025-3600OPT80 +OPT06 + OPT21	UNIT-HYDRAULIC POWER, 28-34 GPM (208V 60HZ)	
GSB2900017	56310GG1BC	05-7025-3600OPT81 +OPT06 + OPT21	UNIT-HYDRAULIC POWER, 28-34 GPM (230V 60HZ)	

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
GSB2900018	56310GG2BC	5630ZZ2BC	UNIT-HYDRAULIC POWER, 28-34 GPM (380V 60HZ)	
GSB2900019	56310GG3BC	5630ZZ3BC	UNIT-HYDRAULIC POWER, 28-34 GPM (460V 60HZ)	
GSB2900020	56310GG4BC	5630ZZ4BC	UNIT-HYDRAULIC POWER, 28-34 GPM (575V 60HZ)	
GSB2900021	56310GG5BC	5630ZZ5BC	UNIT-HYDRAULIC POWER, 28-34 GPM (200V 50HZ)	
GSB2900022	56310GG6BC	5630ZZ6BC	UNIT-HYDRAULIC POWER, 28-34 GPM (220V 50HZ)	
GSB2900023	56310GG7BC	5630ZZ7BC	UNIT-HYDRAULIC POWER, 28-34 GPM (380V 50HZ)	
GSB2900024	56310GG8BC	5630ZZ8BC	UNIT-HYDRAULIC POWER, 28-34 GPM (415V 50HZ)	
GSB2900025	56310GG9BC	5630ZZ9BC	UNIT-HYDRAULIC POWER, 28-34 GPM (440V 50HZ)	
GSB2910008	06-8082-6000		Hydraulic Test Block	
GSB2910009	06-8122-6000		Pressure Relief Valve Test Kit	
GSB3210003	99-8041-6000		Near/Far Test Target	
GSB3240002	14-6806-6011	14-6806-6010	KIT - GAUGING TIRES (0-300 PSI)	
GSB3241003	14-6801-0120	14-8013-0110	Tire Beadbreaker	Z-1063-11+ Z1063-13 + Z- 1063-16 + Z1063-17 + Z1063- 19
GSB3241004	14-6801-0120		Tire Beadbreaker	Z-1063-11
GSB3241005	99-8067-6000		NLG Axle Nut Socket	
GSB3241006	99-8068-6000		MLG Axle Nut Socket	
GSB3241009	14-6801-0120		Tire Beadbreaker	Z-1063-19
GSB3241010	14-6801-0120		Tire Beadbreaker	Z-1063-13
GSB3241011	14-6801-0120		Tire Beadbreaker	Z-1063-16
GSB3241012	14-6801-0120		Tire Beadbreaker	Z-1063-17
GSB3242003	14-6871-6010	99-8027-6010	Anti-Skid Tester	
GSB3242005	K-3025	R1722	ADAPTER-ANTI-SKID TESTER	
GSB3246002	14-6874-6000	99-8042-6000	Anti-Skid Spin-Up Tool	
GSB3250001	99-8065-4000		NLG Transfer Tube Extractor	
GSB3250002	99-8098-6000		NLG Transfer Tube Seal Installation Tool	
GSB3340001	99-8128-4000		Alignment Tool, Outboard Landing Light	
GSB3340002	99-8129-4000		Alignment Tool, Inboard Landing Light	
GSB3411009	99-8057-6000		Pitot-Static Test Adapter Set	

Tronair - GSB Cross-Reference, Feb. 20. 2006

BOMBARDIER GSE P/N	TRONAIR P/N (CURRENT)	TRONAIR P/N (OLD)	DESCRIPTION	REQUIRED OPTIONS, PARTS, ETC. (Used with P/N)
GSB3411011	99-8076-6000		Pitot-Static Test Set	
GSB5235001	99-8106-4000		Baggage Door Counter- Balance Spring Puller	
GSB5411002	99-8093-6000		Cover - Engine Cowl	
GSB6110003	08-8064-4000		Propeller Torque Adapter	
GSB6110006	08-0504-4000	08-8045-4000	Propeller Stationary Stand	
GSB6110008	08-2016-0000	08-8044-0000	Propeller Transport and Build-Up Stand	
GSB6110011	08-0702-6000	08-8024-6000	Propeller Pitch Change Tool	
GSB6110012	99-8071-6000		Propeller Nut Ratchet Wrench	
GSB6110025	08-8056-6000		Propeller Seal Removal Tool	
GSB6110026	08-0111-6000	08-8090-6000	Propeller Blade Lifter	
GSB6120001	08-8077-6000		Torque Motor Tool	
GSB7100015	08-0112-4000	08-8008-4000	Engine Sling	
GSB7100018	08-0132-0000	08-8004-0000	Nacelle Mounted Engine Hoist	
GSB7100019	08-2014-0000	08-8046-0000	Engine Transport Stand	
GSB7100020	08-0113-4000	08-8023-4000	Reduction Gearbox Sling	
GSB7610001	08-8050-6000		Power Level Rigging Tool	
GSB7610002	08-8051-6000		Condition Lever Rigging Tool	
GSB7610003	99-8125-6000		Power Level Angle Rigging Tool	