

Battery Lifts

Tronair recommends performing preventative maintenance on Battery Lifts.

Model Number _____ Serial Number _____

Maintenance Performed By _____ Date _____

Before Each Use: Visually inspect unit to ensure all components are present and functional

- All pivot bolts & nuts are secure
- Cylinder is free of leaks & relief valve is operational
- All casters & locks are operational
- No bent or broken components

WARNING! Ensure lift components are free of damage and or excessive wear.
Never use lift if any component is bent or broken

Periodic Maintenance:

- Lubricate lift
 - All pivot points
 - Threaded adjustment areas
- Ensure Fluid is at acceptable level. Replenish with MIL-5606
- Flush reservoir if fluid is contaminated

Annual (12-Month) Maintenance:

- Ensure lift has been load certified. Check for applicable codes for requirements on annual load testing certifications