

Transport Carts

Tronair recommends performing preventative maintenance on Transport Carts.

Model Number _____

Serial Number _____

Maintenance Performed By _____

Date _____

Before Each Use: Visually inspect unit to ensure all components are present and functional

- Keep units clean and free from any contaminants
- Correct any problems prior to unit operation

Weekly Maintenance:

- Maintain tire pressure 45-50 psi (3.1-3.4 bar)
- Inspect manifold inlet hoses for cracks and kinks
- Inspect output hoses for cracks and kinks
- Visually inspect for any system leaks or damage

Quarterly Maintenance:

- Grease wheel bearings

Annual (12-Month) Maintenance:

- Inspect and calibrate oxygen/nitrogen gauges