

Defuler Service Equipment

Tronair recommends performing preventative maintenance on Defuler Service Equipment.

Model Number _____ Serial Number _____

Maintenance Performed By _____ Date _____

Before Each Use: Visually inspect unit to ensure all components are present and functional

- All component mountings are secure
- All hoses are free of cuts, abrasions, kinks or breaks
- All wheels are secure and operational
- No bent or broken components
- Inlet & outlets are free of contamination

Periodic Maintenance:

- Operation
 - Wheels - lubricate as required
 - Shut-off valves
 - Static reels, clamps and cable operation
 - Air regulator & gauge for operation
 - Replace or tighten any loose or missing fasteners
- Pump
 - See Lincoln manual in Appendix I of CPL for maintenance instructions
 - Pressure relief valve for operation
- Filter
 - If performance is hindered, service filter
 - With unit idle, and no pressure in system, drain canister to check for contamination