

Transport Carts

Tronair recommends performing preventative maintenance on Transport Carts.

Model Number _____ Serial Number _____

Maintenance Performed By _____ Date _____

Before Each Use: Visually inspect unit to ensure all components are present and functional

- Keep units clean and free from any contaminants
- Correct any problems prior to unit operation

Weekly Maintenance:

- Maintain tire pressure 45-50 psi (3.1-3.4 bar)
- Inspect manifold inlet hoses for cracks and kinks
- Inspect output hoses for cracks and kinks
- Visually inspect for any system leaks or damage

Quarterly Maintenance:

- Grease wheel bearings

Annual (12-Month) Maintenance:

- Inspect and calibrate oxygen/nitrogen gauges

www.tronair.com

Tronair • Email: sales@tronair.com • Phone: 419-866-6301 or 800-426-6301 • Fax: 419-867-0634

Asia Sales Offices: China - Email: tronairchina@tronair.com • Phone: 86-592-5560735 • Fax: 86-592-5563132

Asia/Australia - Email: tronairasia@tronair.com • Phone: 66-2665-6511 • Fax: 66-2204-1858

Europe, Middle East & Africa Sales Office • Email: saleseurope@tronair.com • Phone: 44-0-113-245-3300 • Fax: 44-0-113-322-0436